# CATALON

FIBROUS ION-EXCHANGE MATERIAL





A new dawn for water treatment.
In 2014 the fibrous ion-exchange material of new generation was created at the Geyser company.



### The patient on CATALON material



#### Patent claim

«This device belongs to the production of the filter material with strong adsorbing characteristics, vid the fibrous filter material and its method for the production and application. This material can be used for viruses deactivation during water filtration through its layer/s...»



#### What is CATALON?

Catalon is the fibrous ion-exchange material created at the Geyser company that stands to reason of the unique manufacturing process of filtering materials. In 2014 the Geyser company leapt forward in synthesizing of fibrous materials with advanced sorption properties that can destroy viral and bacterial envelopes. The results of investigation are confirmed by the patent for an invention. Also the patent for the material protects the manufacturing process (original chemical substances and the way of their intermixing).







#### **Elektro-adsorbtion**






Multiple experiments and tests have confirmed that Catalon has the same viruses removal mechanism as Aragon. The fibrous sorbent surface has high electrokinetic potential and gradient electrostatic field appears around it. This electrostatic field is able to destroy viruses cover even if they are very far from the surface. This viruses removal method is safe for a human and resource-unrestricted. High electrokinetic surface potential was derived by the patented way of chemical substance mixing during the synthetic process. As a result, active groups of heteropolar charges appear on the material surface layer.



### **CATALON** peculiarities




It means that Catalon removes not only cations:

- copper
- cadmium
- lead

#### but anions:

- organic impurities
- chloroorganics
- iron-depositing bacteria
- colloidal iron





### **CATALON** peculiarities

Catalon works with silver particles well. That not only allows us to integrate silver into the material but also prevents silver outwashing.

Silver is important water clearing element that prevents bacterial growth inside the filtering module.







## A new dawn for water treatment by Geyser jug filters

For the first time the constructed jar filter cartridge let us drink water without boiling.

Now the jar filters Geyser with the cartridge Catalon protect you against viruses 100%.



How have we achieved this?



### Jug filters cartridge with CATALON

New technology of layer sorbing agent filling applied allows it to evade occurrence of wall and tunnel effects that is of great importance for effective viruses and bacteria removal.

- 1 Filtering layer made of ampholitic fibre Catalon In comparison with other fibrous materials it removes not only hard metals (iron, copper, lead, etc.), but also organic impurities, colloidal iron, viruses.
- Filtering and conditioning layer
  It consists of high quality coconut charcoal
  and amberlite resin. It removes chlorine, organic
  impurities, pesticides and it improves
  water taste.
- Final protection cover made of modified fiber Catalon Contact time between water and filtering media increases because of this layer structure. Thereby, there are circumstances for regular distribution of flows (wall effect is prevented). Bacteria growth is eliminated, viruses are removed. This layer also provides anti-discharge and self-indication.


### Experimental results of estimate of cartridge with Catalon barrier function using the model virus coli phage f2.

No	Cartridge type /	Type of coli phage	Coli phage initial	Coli phage	Purification
	Water passing-through time	f2 investigation	concentration, PFU	concentration after	efficiency, %
				cartridge, PFU	M TO MOST
1	V1 Blanc / 4 min. 5 sec.	Agar-layer			Source water does
		technique (direct			not contain coli
	V1 Blanc/ 4 min. 5 sec.	addition)			phages
		Membrane			
2	V1 Hard water/ 4 min.	Agar-layer	$1x10^3$ в $100$ см $^3$	0	100
		technique (direct			
	V1 Hard water/ 4 min.	addition)	$1x10^3$ в $100$ см $^3$	0	100
		Membrane			
3	V1 Soft water/ 4 min. 10 sec.	Agar-layer	$1x10^3$ в $100$ см $^3$	0	100
		technique (direct			
	V1 Soft water/ 4 min. 10 sec.	addition)	1х10 <sup>3</sup> в 100 см <sup>3</sup>	0	100
		Membrane			
4	V2 Soft water/ 4 min. 30 sec.	Agar-layer	1х10 <sup>3</sup> в 100 см <sup>3</sup>	0	100
		technique (direct			
	V2 Soft water/ 4 min. 30 sec.	addition)	1х10 <sup>3</sup> в 100 см <sup>3</sup>	0	100
		Membrane			
5	V3 Soft water/ 4 min.	Agar-layer	1х10 <sup>3</sup> в 100 см <sup>3</sup>	8 в 100 см <sup>3</sup>	99,2
1		technique (direct			
	V3 Soft water/ 4 min.	addition)	1х10 <sup>3</sup> в 100 см <sup>3</sup>	9 в 100 см <sup>3</sup>	99,1
		Membrane			



### Test results of the cartridge with CATALON


Purification water high in iron content (0.4 mg/l, MPC = 0.3 mg/l).





## Test results of The cartridge with CATALON

Lead level of water is 0,06 mg/l. The MPC is 0,03 mg/l.






## Test results of The cartridge 501 with CATALON



Index	Content in water	MPC	
Chloroform	0,2 mg/l	0,2 mg/l	
Chlorine	0,51 mg/l	0,3-0,5 mg/l	
Copper	1,128 mg/l	1,0 mg/l	
Iron	0,42 mg/l	0,3 mg/l	



Filtered water volume (I)



#### New SKU with the CATALON material

Now available: all the 500 series cartridges with Catalon material.





# Goods in which the above technologies were exploited.









FIBROUS ION-EXCHANGE MATERIAL





For more information please visit:

www.geizer.com